



## PL998 – Push Button Wall Safe

### Setting or Changing your Sentinel Lock Combination

1. Open the keypad cover.
2. Push down the opening lever.
3. Remove the clear setting key on the back of the lock panel.



Setting Key  
Yellow Dials

NOTE: Make a note of your chosen combination before setting your lock

4. Push down and turn the yellow dials of your chosen combination 180° with the setting key. Repeat with all digits of your chosen combination.
5. Replace setting key and **test combination before closing** the lock door.
6. Once combination is set, close lock panel door and pull down the clear lever (black lever between 0 and \* buttons).



Yellow dial set (on) pointing away from you  
Yellow dial unset (off) pointing towards you

### Mounting your Sentinel Wall Safe

We suggest that you mount your Sentinel Lock in a discreet location away from direct view such as porches, garages, away from direct view

NOTE: You will need the following:

X-head/Pozidriv  
Screwdriver



Pencil



Spirit Level



Drill



Hammer



1. Open the Sentinel door
2. Position the lock on the chosen mounting surface
3. Use the spirit level to make sure the lock is vertical
4. Mark with a pencil the position of the screw holes (see image)
5. Remove the lock and drill holes
6. Use the hammer to fit rawlplugs into the wall
7. Position the lock, insert, and tighten screws
8. Close the Sentinel door



NOTE: There is a clear lever between the 0 and \* on the bottom of the lock door (button side), this can be pulled down and will let you input your code again, similar to the clear button on a card reader.

