

## PL997 – Push Button

## **Changing your Sentinel Lock Combination**

- 1. Open the key pad cover
- 2. Push down the opening lever
- 3. Remove the clear setting key on the back of the lock panel

NOTE: Make a note of your chosen combination before setting your lock

- 4. Push down and turn the yellow dials of your chosen combination 180 degrees with the setting key. Repeat with all digits in the chosen combination.
- 5. Replace setting key and test combination before closing the lock panel
- 6. Once combination is set, close lock panel door and pull down the clear button

## Lock Shackle

- 1. Open your sentinel lock
- 2. Slide and hold the release lever in the direction of the arrow, at the same time pull the shackle up.
- 3. Fix to suitable anchor
- 4. Hold leaver in the direction of the arrow and push leaver back into fixina
- 5. Release lever



